



- 1- Assemble cistern fittings and mount cistern to pan, ensuring the rubber seal is correctly positioned between the two. Fix together with connecting bolts provided and tighten equally until cistern is rigid.**
- 2- Place suite in position, ensuring cistern touches the wall only at the top. Do not force the cistern flat against the wall as this could impair operation of the cistern and toilet seat. Connect the waste outlet to the soil pipe.**
- 3- Mark the positions of wall and floor fixings. Remove the suite and drill/plug as required. Re-connect the suite. Fix the pan to the floor with the Roca fixing kit provided and fix cistern to wall with 2x8 mm screws (not included).**
- 4- Fit toilet seat, tightening equally each side. Check seat operates satisfactorily. Protect until installation is complete.**