



PL **SAONA**
instrukcja montażu i eksploatacji

CS **SAONA**
návod na montáž a údržbu

DE **SAONA**
montage-und betriebsanleitung

EN **SAONA**
instructions for assembly and use

ET **SAONA**
paigaldus- ja kasutjuhend

HU **SAONA**
szerelési és üzemeltetési utasítás

LT **SAONA**
montavimo ir eksploataavimo instrukcija

LV **SAONA**
montāžas un ekspluatācijas instrukcija


RO **SAONA**
instrucțiuni de montaj și operare

RU **SAONA**
инструкция по монтажу и эксплуатации


SK **SAONA**
návod na montáž a údržbu


UK **SAONA**
інструкція по монтажу і експлуатації

A




B









	1	2	3	4	5	6	7	8	9	10
A	4	4	8	16	4	4	---	2	6	6
B	4	4	8	16	4	4	2	2	10	10




	11	12	13	14	15	16	17	17.1	18	19	20
A	2	2	2	2	2	2	2	---	14	18	6
B	2	2	2	2	2	2	2	2	14	22	6




	21
A	6
B	6









A B










5-10 mm




B

A B







A









B





A B




A B





A B




A B




A B





A B



A B

